

PRODUCT-DETAILS

8504.3 BB

Rocker push button Symbol "bell" for Switch/push button, Single rocker White - Sky Niessen



General Information

Extended Product Type	8504.3 BB
Product ID	2CLA850430A4101
EAN	8427238239453
Catalog Description	Rocker push button Symbol "bell" for Switch/push button, Single rocker White - Sky Niessen
Long Description	Color: Soft White Basic Rocker for push-buttons code: 8104, 8104.5 & 8104.9

Installation

Instructions and Manuals	2CLX850009A1001
--------------------------	-----------------

Popular Downloads

Marketing Video	9AKK106930A1594 9AKK108468A9590
-----------------	------------------------------------

Eco Transparency

Environmental Product
Declaration - EPD

9AKK108468A7379

Technical

Data Sheet, Technical Information	9AKK107046A0356
Application	Switch/push button
Design Range	Sky Niessen
Type of Fastening	Clamp
Surface Finishing	Untreated Matt
Material	Plastic Thermoplastic
Legend	Symbol "bell"
Model Number	Single rocker
RAL Number	RAL 9010 - Pure White
Color	White
Number of Batteries	0

Environmental

Ambient Air Temperature	Operation -5 ... +35 °C Storage -5 ... +50 °C
Degree of Protection	IP20
RoHS Status	Following EU Directive 2011/65/EU and Amendment 2015/863 July 22, 2019
RoHS Information	2CLC850430A4101
REACH Declaration	9AKK108467A7464
Environmental Information	9AKK108466A4732
Conflict Minerals Reporting Template (CMRT)	9AKK108468A3363

Dimensions

Product Net Width	0.081 m
Product Net Height	0.078 m
Product Net Depth / Length	0.131 m
Product Net Weight	0.022 kg

Certificates and Declarations

Declaration of Conformity - CE	No declaration needed
--------------------------------	-----------------------

Classifications

ETIM 8	EC000011 - Control element/cover plate for domestic switching devices
ETIM 9	EC000011 - Control element/cover plate for domestic switching devices
WEEE Category	5. Small Equipment (No External Dimension More Than 50 cm)
WEEE B2C / B2B	Business To Consumer

CN8

85389099

UNSPSC

39121704

Categories

Low Voltage Products and Systems → Wiring Accessories - Light Switch Ranges → Cover Plates and Control Elements → Mechanical Controls

